



**INSTALLATION PROCEDURES**  
**BOOMERANG™ SURFACE-MOUNT DELINEATORS USING**  
**BITUMIN ADHESIVES**

To assemble post and base:

1. Mount post over riser on base and insert two (2) hex bolts (¼"-20 x 2-½") through the post. Attach a Nyloc nut to each bolt and tighten to secure the post to the base.

Please note the following prior to installation:

1. Posts that are to be mounted on the ground with adhesives require a clean surface prior to installation. Make sure all dirt, dust (even fine dust), rocks, and/or gravel have been cleared from the surface. For best results after sweeping, use compressed air to blow any fine particles from the surface. If surface is wet, it is always recommended to torch surface to remove moisture. The bottom of the base should also be clean of any dust prior to installation.
2. When dealing with any sort of bitumen, use gloves at all times during mixing and installation. Bases manufactured by Three D Traffic Works, Inc. do not require flame treating.
3. Units are to be spaced evenly according to specifications required by the instructions or manuals for each individual user, contractor, city, state or federal agency.

To install unit (assembled):

1. Kettle temperature for Bitumen varies and should be mixed according to the manufacturer's recommendation to assure the Bitumen "stands up" when poured. This will allow the Bitumen to penetrate the holes on the TD5200 Base.
2. Place bitumen on cleaned surface and mount unit onto the bitumen. Make slight turn once left then back right to remove air bubbles and allow bitumen to ooze into holes in base.
3. Do not fill inside cavity of base with bitumen. Be sure to align base with arrows facing traffic.