



**INSTALLATION PROCEDURES**  
**SENTINEL™ GROUND-MOUNT FLEXIBLE DELINEATOR**  
**TD5600 SERIES**

Please note the following prior to installation:

1. The Sentinel™ (TW-500) posts come with an optional 18" u-channel soil anchor for compacted or heavy soil conditions, or a plastic soil barb designed to facilitate anchoring in loose, sandy or wet soils.
2. Sentinel™ (TW-500) ground-mount delineators are to be spaced evenly according to specifications required by the instructions or manuals for each individual user, contractor, city, state or federal agency.

To install unit:

1. Using the TD5600 Pilot Hole driver, place the spade end of the driver at the desired post hole location. Grabbing the driver collar, slide the upper portion of the driver up and then downward with sufficient force to drive the spade into the soil. Repeat until spade is buried approximately 18 inches deep. Remove the Pilot Hole driver spade by sliding the upper portion of the driver upward making contact with the top of the driver. Repeat until the entire driver is removed from the hole.
2. Place the Sentinel™ post into the TD5600 Post driver and place the tip of the post into the pilot hole. Slide the Post Driver up and then downward onto the post. It will require little pressure to start the post into the pilot hole. Increased downward pressure can be increased once post is halfway into the pilot hole. Place toe of shoe on back of post during driving operation for additional post support.
3. Be careful to maintain the post in a vertical position during the driving process, adjusting the post between impacts if necessary. Drive post into soil to a depth of 18 inches.