



INSTALLATION PROCEDURES
ROADGUIDE BRIDGE AND CONCRETE BARRIER MARKERS
TD9400 SERIES

Permanent Installation:

1. Clean the area where the marker will be installed. The surfaces should be clean of dust, dirt, oil and moisture.
2. Apply adhesive 1/8" thick across the bottom of the marker, corner to corner and across.
3. Place the marker on the barrier and apply firm pressure for at least five seconds.
4. Marker will have final bond strength after 72 hours.

Temporary Mounting Using Butyl Adhesive Pad

1. Spray the area where the marker will be applied with primer. Allow primer to sit for one (1) minute.
2. Remove paper from butyl pad.
3. Place the marker on the barrier and apply firm pressure for at least five seconds.